


# MICROBORE UNIT SPARES IDENTIFICATION SHEET



All units are supplied complete as shown including an insert key , but less inserts.

Replacement cartridges are supplied with insert screw, but less inserts.

To improve rigidity when cut depth exceeds 0,5mm, it is recommend that the top adjustment springs be removed. See standard boring bar range catalogue page 21 for setting information.